







OWNER'S MANUAL

Model No. 95005E


CAUTION:

- 1) Keep away from fire.
- 2) Product not to be used for camping.
- 3) Do not put flammable materials in or near the Play House.
- 4) Never use electrical devices inside or near Play House.
- 5) Remove all debris from set up area before setup.
- 6) Adult assembly required.
- 7) Never allow children to use the Play House while unattended.

PARTS LIST

A	B	C	1	2	3
					
49.5 cm (19.5 in)	36.0 cm (14.2 in)	38.0 cm (15.0 in)			
Straight Tubes	Straight Tubes	Straight Tubes	Straight Connectors	Connectors	Connectors
14 PIECES	4 PIECES	8 PIECES	11 PIECES	6 PIECES	4 PIECES

ASSEMBLY INSTRUCTIONS



Bestway®

©2023 Bestway Inflatables & Material Corp.

All rights reserved

Trademarks used in some countries under license from **Bestway Inflatables & Material Corp., Shanghai, China**

Exported by **Bestway (Hong Kong) International Ltd./Bestway Enterprise Company Limited**

Suite 713, 7/Floor, East Wing, Tsim Sha Tsui Centre, 66 Mody Road, Kowloon, Hong Kong

Distributed in North America by **Bestway (USA) Inc., 3435 S. McQueen Road, Chandler, AZ 85286, United States of America**

Tel: +86 21 69135588

www.bestwayusa.com