

## **Hot Tub Installation Safety Reminders**

\*\* Read your manual thoroughly before installation \*\*

### **Installation Location**

Ensure the installation location is level and able to support the combined weight of the product when filled and all its users. The location must have adequate drainage to avoid property damage and be within 12 ft. of a grounded, grounding-type receptacle.

Special Indoor Installation Requirements: Outdoor setup is preferred, but if an indoor location is chosen, note that humidity is a natural side effect of hot tub use and could cause damage to property without proper precaution. To minimize these effects, consult an expert to confirm the installation area is properly ventilated prior to use.

### **Electrical Safety**

Use of an extension cord or multi-plug adaptor is strictly prohibited. Plug your 12 ft. hot tub cord directly into a grounded socket to avoid overheating, which can lead to damage of hot tub equipment and surrounding property.

Your hot tub must be used with a grounded socket corresponding to the electrical rating of the attachment plug (110-120V AC, 60Hz, Single Phase 12A at 68°F). It is recommended to use a socket that is also resistant to humidity and capable of high-power loading. If you're unsure about the electrical supply quality, consult a qualified electrician before use.

It's important to regularly inspect the plug and socket for signs of damage. If signs of damage are found, do NOT plug back into the socket.